

# Remote Volume Control Panel

## Model RVCP

---

### General

---

The RVCP fits in a standard single gang electrical box and may be installed using the included hardware. Be sure to make all electrical connections prior to installing the RVCP into an electrical box.

### Electrical Connections

---

Minimum 24-gauge, 3 conductor wire is recommended. Maximum wire length run of 2,000 feet.

Connect similarly labeled terminals on the Bogen amplifier or control unit and RVCP together. UP to UP, Common (C) to Common (C), and down (DN) to down (DN).

#### ***DAISY-CHAINING***

Multiple RVCP's can be daisy-chained from control panel to control panel for multiple locations. Parallel like labeled terminals on each RVCP together.

### Orientation

---

Make certain that the RVCP is in the proper orientation when it is installed. The arrow on the back should be pointing up towards the ceiling.